

QUICK START

Tecra®

Z50–A Series

Check the components

Your computer comes with:

- AC adaptor and adaptor cord
- Power cord/cable
- Documentation, including this Quick Start document and a Standard Limited Warranty
- Other components, depending upon model

▲ WARNING Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause birth defects or other reproductive harm. ***Wash hands after handling.***

- ▲ CAUTION**
- Avoid prolonged physical contact with the underside or surface of the computer.
 - Computer base and palm rest can become hot! Avoid prolonged contact to prevent heat injury to skin.

Note: The computer's battery is not accessible by the user.

Notice

- Certain computer chassis are designed to accommodate all possible configurations for an entire product series. Your select model may not have all the features and specifications corresponding to all of the icons or switches shown on the computer chassis, unless you have selected all those features.
- **Subject to Change.** Product specifications, configurations, prices, system/component/options availability are all subject to change without notice.

Getting started

Connect to a power source

Assemble the power cord/cable and AC adaptor and then connect it to your computer and a live electrical outlet. You are now ready to start using your computer.

Connect to the Internet

Connect to a network to take full advantage of your computer's features.

Backup your computer


It is strongly recommended that you create a back up of your computer before using it for the first time. This will enable you to return it to its out-of-box state, if necessary. For complete instructions on how to create recovery media, see the "Creating recovery media" section in the electronic User's Guide.

Register your computer


Enhance your ownership experience by taking a few minutes to register your Toshiba Product at **register.toshiba.com**. Completing Product registration allows Toshiba to provide you with Product information updates, special offers and promotions. Failure to complete Product registration will not diminish your rights under the Standard Limited Warranty.

Quick Tour

Front with display open




Underside




*Available on certain models.


Front with display closed



Back




Left side



*Available on certain models.

Right side



*Available on certain models.

Navigation

The Start screen contains tiles that are shortcuts to your apps and programs. Right-click on the background or swipe up from the bottom edge or swipe down from the top edge and select **All apps** to see more.

Keyboard shortcuts



Toggles between the Start screen and the last opened app




To go to the Desktop or select the Desktop tile




To reveal the charms

Mouse navigation



Move your pointer to the upper-right corner of the screen to reveal the charms.



Search – Allows you to locate items (apps, photos, music, documents) on your computer

Share – Allows you to share items (links, photos, and more)

Start – Takes you to the Start screen or, if you're already on the Start screen, returns you to your last app

Devices – Allows you to manage your hardware

Settings – Allows you to access your computer's settings (volume, brightness, connecting to the internet, and more)

Internet connectivity

1. Move your pointer over the upper or lower right corner of the screen. When the Windows® charms appear, click/touch the **Settings** charm.
2. Click/touch the **Wi-Fi** icon. The Networks screen appears. Select your network. Click/touch **Connect**.
3. Enter the network security key (if applicable). Click/touch **Next**. Your computer should be connected.

Turn off your computer

Move your pointer to the upper-right corner of the screen or swipe in from the right edge to reveal the charms.

Click/touch the **Settings** charm.

Select **Power** then **Sleep/Shut down/Restart**.

General Safety Instructions

Please read the following safety and operating instructions before using your Product. Keep the information near your Product for future reference.

To reduce the risk of fire, bodily injury and/or damage to your Product, please observe all of the following instructions:

AC Adaptor

Always use the Toshiba AC adaptor that was provided with your Product or as specified by Toshiba.

Base or Palm Rest

Avoid extended contact between Product base or palm rest and your skin. Under certain operating conditions such as prolonged contact may result in skin irritation and/or heat injury. Consider using a hard computer insulating pad or similarly suitable hard insulating material when using Product on your lap.

(Internal) Battery

Your Product may contain an internal battery for powering the real-time clock. Replacement or service should be done by an authorized Toshiba service provider.

Circulation and Cooling

Allow sufficient air circulation around Product and AC adaptor during use and while charging the battery to ensure adequate cooling of the device. Prevent direct exposure to heat sources.

Cleaning

Unplug Product from the electrical outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. The injected combustible gas produced by these types of cleaners may remain inside of your product. The electrostatic spark from the motor or contact point of switch may ignite the gas residue, which could result in an explosion, fire, or burn injury. Instead use a lightly dampened cloth for cleaning in general and remove dust with a dry cloth.

Comfort Recommendations

When you use your Product, rest your eyes periodically and relax or stretch your muscles to avoid strain. Adjust your chair, feet and Product accordingly to achieve optimal working posture. Please refer to Toshiba's "User Comfort Recommendations" in the User's Guide.

Viewing Recommendations

Some individuals may experience health-related complications when exposed to certain images or flashing lights (for example when playing videos or games). Discontinue use and consult a physician if you experience any health-related complications.

Choking Hazards

Keep Product away from small children. This Product is not a toy and may be hazardous to small children, for example, small detachable parts may be a choking hazard.

Disassembly

Do not disassemble, modify, tamper with or repair your Product.

Disposal

Dispose of Product or any components in compliance with all applicable laws.

Foreign Objects

Never push a foreign object through an opening in the Product. Never allow metal objects (such as screws, staples, or paper clips) to enter Product. This could cause a short circuit.

Heat

Keep Product away from radiators, stoves, heat sources or other equipment that produce heat.

Hot Surfaces

Allow the equipment's internal components and hot-pluggable drives to cool before touching them.

Unstable Surfaces

Do not use Product on an unstable table, cart or stand.

Operating Environment

Never expose your Product to excess heat, extremely low temperatures, sudden temperature variations, or dusty environments. This could cause system malfunction, loss of data or damage to Product.

Power Cables/Cords and Power Source

Always use power cables/cords and power sources that comply with the voltage and frequency specifications and requirements of the country of use.

Service Provider

Disconnect Product from the electrical outlet and take Product to an authorized Toshiba service provider if:

- AC adaptor or power cable/cord is damaged.
- Liquid has spilled into Product or an object (such as a screw, staple or paper clip) has entered Product.
- Product has been dropped, subject to shock or impact and/or damaged in some way.
- Noticeable signs of overheating, smoke, deformation, cracks, leaks or unusual odor occur.
- Service is needed on component inside compartments requiring opening or removal of covers.

Thunderstorm

Never operate your Product during a thunderstorm. An electrical surge caused by the storm may cause system failure, loss of data or hardware damage.

Wireless Functionalities

Turn off your Product and/or all wireless functionalities where electronic devices are regulated or controlled or when near a person with any medical electric devices.

Ventilation

Operate your Product on a hard flat surface to ensure reliable operation and good ventilation. Using your Product on a soft surface such as carpet or sofa can block slots, vents or openings and cause overheating.

Water and moisture

Do not use Product in a wet location. Do not connect/disconnect a power plug/cord with wet hands.

Need Help?

Most problems are easy to correct. Save time with one of these simple solutions.

Consult the electronic User's Guide

(Internet connection required)

Start Screen

To access the electronic User's Guide through your Start screen

1. Click/touch the **TOSHIBA Central**  tile/icon
2. Click/touch **User's Guide**

Note: The User's Guide will be automatically downloaded and saved on your computer so that you can access it at a later time. The User's Guide opens in the default PDF reader software; you may be required to complete a setup process.

For solutions to the most common problems, refer to the "If Something Goes Wrong" section of the User's Guide.

Visit Toshiba's Support Web site

Technical support is available online at Toshiba's Web site at **support.toshiba.com**. At this Web site, you will find answers for many commonly asked technical questions plus many downloadable software drivers, BIOS updates, and other downloads.

Tegra, AccuPoint, and eco Utility are registered trademarks or trademarks of Toshiba America Information Systems, Inc. and/or Toshiba Corporation. HDMI, the HDMI Logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing, LLC. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Wi-Fi is a registered trademark of the Wi-Fi Alliance. All other brand and product names are trademarks or registered trademarks of their respective companies.

 Printed on recycled paper

TOSHIBA
Leading Innovation >>>



©2013 Toshiba America Information Systems, Inc.

GMA501233010 • 10/13